



SNS-101 (Ref. 5101)

FTA or Multicrypt DVB-S → IP Streamer — Common Interface

Configuration and Settings

User Manual



Configuration and Setting of the SNS-101 Streamer Module
User Manual

November 2008
Revision C

IKUSI - Ángel Iglesias, S.A.

Paseo Miramón, 170
20009 San Sebastián
SPAIN

Tel.: +34 943 44 88 00

Fax: +34 943 44 88 11

www.ikusi.com

CONTENTS

Introduction	4
This Manual	4
Product Description	4
 Chapter One - Configuration of the SNS-101 Streamer	5
Configuration	6-10
Save/Restore Configuration	11
General Report	12
 Chapter Two - SNS-101 Streamer Settings	13
DiSEqC Configuration	14
Input Settings	15-17
Output Settings	18-20
SAP Channel Settings	21
CAM User Menu	22
SNMP Configuration	23/24
 Chapter Three - SNS-101 Streamer Status Information	25
Status Information	26
 Chapter Four - SNS-101 Streamer Reports	27
Input Services	28
Output Streams	29
System Logs	30

Introduction

This Manual

This manual describes the configuration and settings programme for the SNS-101 Streamer Module. It is the second part of the user documentation for said module, the first part of which is the Installation and Access manual supplied in paper format.

Product Description

SNS-101 streamers are DVB-S to IP gateways designed to broadcast in multicast on an IP network the services (TV or Radio programmes) issued from FTA or encrypted digital satellite reception; in case of encrypted signal, a CAM containing the operator's smart card must fit the front panel slot. The IP streams can be viewed using an IPTV set-top box or a software video player.

SNS-101 modules have an IKUSI ClassA mechanical format. As such, they are fixed to BAS-700 / BAS-900 baseplates or to an SMR-601 rack frame, and are +12 VDC powered from a CFP module.

Characteristics

- Input: 1 DVB-S transport stream (MPTS). Output: up to 8 simultaneous, IP-encapsulated services (TV or Radio programmes), with individual multicast addresses.
- Information filtering of MPEG-2 tables.
- UDP & RTP transmission protocols.
- Web interface for configuration and setting.
- Alarm information SNMP agent.
- SAP & SDP protocols that facilitate automatic service selection on the user's STB and provide information to external servers.

ADVANCED

PID filtering
PSI/SI parsing
Transparent ECM & EMM messaging
PAT and PMT table regeneration
Routing or blocking for CAT, NIT, SDT, EIT, TDT tables
Configurable QoS marking
Configurable Time To Live

When the connection is established between the SNS-101 streamer and the control PC, the programme access screen appears:



Programme Access Screen


Once the desired programme language has been chosen [English (en), Spanish (es), French (fr)], enter the password and click on **OK**.

Note: The default password — admin — can (and must) be changed as explained on page 9.

Chapter One - Configuration of the SNS-101 Streamer

In this Chapter

- Configuration
- Save/Restore
- General Report



General Configuration

Initial program screen

The first screen that appears when the programme is accessed contains the "Output" window, which gives information on the IP streams that have been created on the module and which may or may not be incorporated into the output data stream.

On the left of this screen are the menus that access all of the programme's functionalities.




Figure 1.1 - Initial programme screen

Click on the **General** menu on the left of the screen to display a dropdown list containing the 3 options: *Configuration*, *Save/Restore* and *General Report*.

Click on *Configuration*. The Configuration window will appear :

Figure 1.2 - Identification card of the Configuration window.

Identification

The identification card (Figure 1.2) provides basic data on the SNS-101 streamer. The different card fields are completed as follows:

"Model": SNS-101. This data cannot be changed.

"Serial Number": Informational data which cannot be changed.

"Firmware Version": As above.

"Identifier": Any name that the installer or operator wishes to assign to the streamer module can be entered here.

"Location": Enter the postcode of the installation site if required.

"Installer": The installer's identification details can be entered here.

"Contact": Then enter their contact details (telephone number, email).

"Installation date": The date on which the streamer module was installed can be entered here.

Click on the *Save* button at the bottom of the window to store the information on the streamer module, this information is then shown each time the module is accessed.

Network

Click on the Network tab to configure the streamer's ethernet connection parameters. The following card is displayed:

The screenshot shows a 'Configuration' window with a 'Network' tab selected. The window has a title bar with a play icon and the word 'Configuration'. Below the title bar are five tabs: 'Identification', 'Network' (selected), 'Password', 'Shutdown', and 'Update firmware'. The 'Network' tab contains the following fields:

- Use DHCP to resolve IP address:** A checkbox that is currently unchecked.
- IP Address:** A text field containing '192.168.1.4' with a placeholder '(xxx.xxx.xxx.xxx)' to its right.
- Network mask:** A text field containing '255.255.255.0' with a placeholder '(xxx.xxx.xxx.xxx)' to its right.
- Network gateway:** A text field containing '192.168.1.1' with a placeholder '(xxx.xxx.xxx.xxx)' to its right.
- Primary DNS server:** A text field with a placeholder '(xxx.xxx.xxx.xxx)' to its right.
- Secondary DNS server:** A text field with a placeholder '(xxx.xxx.xxx.xxx)' to its right.
- MAC address:** A text field containing '0009E3070001'.

At the bottom of the window are two buttons: 'Modify Net Config.' and 'Restore'.

Figure 1.3 - Network card of the Configuration window.

"Use DHCP to get IP address": If this box is checked, the SNS-101 module will use the DHCP protocol for assigning dynamic IP addresses. Consequently, no data needs to be entered in the next five fields on the tab.

If the administrator of the network on which the SNS headend is installed assigns static IP addresses, the box will not be checked and the following fields will need to be filled in.

WARNING: If this option is activated, the IP address assigned to the streamer can only be known by consulting the DHCP server management system.

"IP Address": Enter the IP address that you wish to assign to the streamer. This address must fall within the range of local network addresses.

"Network mask": Enter the local network mask.

"Default gateway": Enter the IP address of this gateway. This information is only required if you want the streamer to access Internet.

"Primary DNS server": Enter the primary server's IP address. Equally, this information is only required if you want the streamer to access Internet.

"Secondary DNS server": Enter the same information for the secondary server.

"MAC Address": The physical address of the streamer's ethernet network card is displayed automatically.

Once you have filled in all of the required information, click on *Modify Network Configuration*. If, at the last moment, you decide to keep the current settings, click on *Restore*.

Password

If you want to change the current access password, click on the Password tab. The following card is displayed:

Figure 1.4 - Password card of the Configuration window.

"Current password": Enter the current password.

"New password": Enter the new password which will be required to access the program the next time.

"Confirm new password": Re-enter the new password.

Once you have entered the required information, click on *Modify* so that the streamer adopts the new access password. If, at the last moment, you decide to keep the previous password, click on *Cancel*.



Note

If you do not know the old password, i.e. the password used to access the current configuration session, you must perform a Password Reset as explained in the Installation and Access manual. Following this reset, the program password will be the default password: admin.

IMPORTANT: When you perform a password reset, the IP address assigned to the streamer on the Network card (previous page) automatically changes to the default setting: `http:// 92.168.1.4`.

Shutdown

If you need to reboot the streamer for any reason, click on the Shutdown tab. The following card is displayed:


Figure 1.5 - Shutdown card of the Configuration window.

Click on *Reboot*. A reset is then performed after which the Output Streams screen will appear, this is the presentation screen of the programme.

Update Firmware

If you wish to update the streamer's firmware, click on the Update Firmware tab. The card displayed (Figure 1.6) shows the firmware version that the streamer has at the present time.

(The firmware is software stored in the module which is responsible for its basic operation).



The screenshot shows a web interface titled 'Configuration' with a play button icon. Below the title is a horizontal menu with five tabs: 'Identification', 'Network', 'Password', 'Shutdown', and 'Update firmware'. The 'Update firmware' tab is selected and highlighted with a dashed border. Below the tabs, the text 'Firmware version:' is displayed. Underneath, there is a label 'Select the update file:' followed by a text input field and a 'Browse...' button. At the bottom of the card, there is a 'Start' button.

Figure 1.6 - Update Firmware card of the Configuration window.

WARNING: The firmware update file will have been previously stored on the PC hard drive. (You can download it from <http://www.ikusi.com>).

Click on *Browse...* and select the firmware update file from the hard drive. When the file name is in the box, click on *Start*. The new firmware will be installed on the streamer and then its name will appear in the card replacing the one of the file before.

Save/Restore System Settings

All of the data established on the streamer module through the various Configuration window tabs can be saved onto a backup file. Inversely, the configuration data saved on an appropriate file can be restored on streamer module.

Click on the **General** menu on the left of the general programme screen and click again on the *Save/Restore* option. The Save/Restore window will appear:




Figure 1.7 - Save/Restore window

Save/Restore Configuration

"Save configuration": Select the option in the window and click on *Start*. A window is displayed which allows you to select the destination folder for the data file for the current streamer configuration.

"Restore Configuration": Select this option in the Save/Restore window (Figure 1.7) and click on *Start*. The Restore Configuration window is displayed (Fig. 1.8) Click on *Browse...* and select the file containing the configuration data that you wish to restore on the streamer module. Once you have selected the file, click on the *Upload File* button at the bottom of the screen. The upload confirmation window will be displayed.





Figure 1.8 - Restore Configuration Window

General Report

Click on the **General** menu on the left of the general programme screen and click again on the *General Report* option. The General Report window is displayed:



The screenshot shows a window titled "General Report" with a red header bar. The content is organized into three sections: "General", "Network", and "Settings". Each section contains a list of parameters and their values.

General	
Identification	
Model:	SNS-101
Firmware version:	200704-r1.01
Identifier:	
Location:	
Installer:	
Contact:	
Installation Date (mm-dd-yyyy):	11-30-1999
Network	
Use DHCP to resolve IP address:	No
IP address:	192.168.1.4
Network mask:	255.255.255.0
Gateway:	192.168.1.1
MAC:	0009E3070001
Settings	
Input	
Setting Mode:	Intermediate Frequency
Intermediate Frequency (MHz):	1936
Input Rate (MS/s):	22000
LNB Type:	Universal LNB
Intermediate Frequency (MHz):	
LO's Low Frequency (MHz):	9750

Figure 1.9 - General Report window


This window provides complete information on the SNS-101 module, not only regarding the configuration described in the previous pages, but also in relation to the current settings parameter values and operational status.

The information contained in this window can be printed by clicking on the *Print page* button at the bottom of the screen.

Chapter Two - SNS-101 Streamer Settings

In this Chapter

- DiSEqC Configuration
- Input Section Settings
- Output Section Settings
- SAP Channel Settings
- CAM User Menu
- SNMP Configuration



DiSEqC Configuration

The SNS-101 module settings are grouped into six sections or categories: DiSEqC, Input, Output, SAP Channel, CAM User Menu and SNMP. Click on the **Settings** menu on the left side of the general programme screen. A drop down list is displayed offering six options: *DiSEqC*, *Input*, *Output*, *SAP Channel*, *CAM User Menu* and *SNMP*.

Click on *DiSEqC*. The DiSEqC Configuration window will appear:

DiSEqC Configuration

Enable DiSEqC: ☐

Number of inputs: 8

Description of each input:

Send

Figure 2.1 - DiSEqC Configuration window — DiSEqC deactivated

"Activate DiSEqC" : Check the box if you want to equip the streamer with DiSEqC function, either because you have to feed/control an LNB or because a multiswitch is installed in the headend. Otherwise leave the box unchecked.

"Number of inputs" : It refers to the number of SAT inputs of the multiswitch (if there is no multiswitch, and the matter is to feed/control an LNB, choose "4"). When choosing, a multiple pop-up box, with a number of rows equal to the number chosen, appears on the field below (see Figure 2.2).

"Description of each input" : If there is no multiswitch and the streamer has to feed/control an LNB, fill the polarity/band columns with the selections that appear in the first four rows of Figure 2.2. If there is a multiswitch, you have to know what IF signal (satellite, polarisation, band) is connected to each one of the inputs of that one; with this information at hand, fill in all the rows of the box.

DiSEqC Configuration

Enable DiSEqC: ☒

Number of inputs: 8

Description of each input:

	Satellite	Polarity	Band
Input 1:	Astra	Vertical (13V)	Low (0Khz)
Input 2:	Astra	Vertical (13V)	High (22Khz)
Input 3:	Astra	Horizontal (18V)	Low (0Khz)
Input 4:	Astra	Horizontal (18V)	High (22Khz)
Input 5:	Hispasat	Vertical (13V)	Low (0Khz)
Input 6:	Hispasat	Vertical (13V)	High (22Khz)
Input 7:	Hispasat	Horizontal (18V)	Low (0Khz)
Input 8:	Hispasat	Horizontal (18V)	High (22Khz)

Send

Figure 2.2 - DiSEqC Configuration window — Description of multiswitch inputs

Once all data is entered, click on *Send* to conclude the DiSEqC configuration.

Input Section Settings

Click on the **Settings** menu on the left of the general programme screen and click again on the *Input* option. The Input window will appear:

The screenshot shows the 'Input' window with a maroon header. Below the header, there are four settings: 'Setting Mode' with a dropdown menu set to 'IF', 'Intermediate Frequency (MHz)' with a yellow input field and red/green adjustment buttons, 'Input Rate (MS/s)' with a yellow input field and red/green adjustment buttons, and 'Input signal' with a red 'X' icon. A 'Save' button is at the bottom left.

Figure 2.3 - Input window

This window is used to enter the settings values for two parameters (intermediate frequency and input rate) and, if the DiSEqC function is activated, to power an LNB or select an input of multiswitch. The intermediate frequency is the transposed frequency of the desired transponder's frequency.

The window has different number of boxes depending on the selection made in the first one ("Setting Mode"), and whether the DiSEqC function is activated or not.

"Setting Mode": Select IF if the intermediate frequency value is calculated by the installer, or Transponder if you wish the programme itself make the calculation.

IF CALCULATION

The SNS-101 streamer's input frequency band is 950-2150 MHz, known as "satellite intermediate frequency" or simply "IF". The value to enter for a particular transponder can be obtained by subtracting the transponder's frequency from the LNB local oscillator frequency.

The operational frequencies are the following:

- Satellite transponder frequency band: 10700-12750 MHz
- Local Oscillator frequency on Standard LNB's. Two possible values:
9750 MHz for 10700-11700 MHz input frequencies (low band)
10600 MHz for 11700-12750 MHz input frequencies (high band)

- **Example of the calculation** for FI relating to the WDR program transponder on the Astra satellite:

Transponder frequency: 11836 MHz
 IF (intermediate frequency): $11836 - 10600 = 1236 \text{ MHz}$

"IF" setting mode is selected:

"Satellite signal": Select from the drop down list (see Figure 2.4) either the voltage/tone signal for feeding/controlling the LNB or the desired input of the multiswitch.



Note

The "Satellite signal" box is shown or not depending on whether the DiSEqC function was activated or not through the *DiSEqC* option of the **Settings** menu.

Figure 2.4 - Input Window — IF Mode

"Intermediate Frequency (MHz)": Enter the value calculated for the transposed intermediate frequency of the transponder's frequency in the box. The latter can be found in specialist magazines.

"Input Rate (MS/s)": This parameter, best known and Symbol Rate, is also provided in specialist magazines. Enter the value in MS/s (megasymbols per second) or MegaBaud.

Once the data is entered, click on *Save* to conclude the input settings.

"Input signal": This indicates whether the streamer module has synchronised (✓) or not (✗) with the input signal. If it has not synchronised, check the different settings values entered.

"Transponder" setting mode is selected:

Figure 2.5 - Input window — Transponder Mode - LNB Standard

The window adds 5 auxiliary boxes to those described above for the "IF" setting mode. The programme itself will complete the "Intermediate Frequency (MHz)" box based on the data entered in the mentioned auxiliary boxes, as indicated next:

"LNB Type": The drop down list has 2 options: Standard LNB and Special LNB.

If the LNB installed on the parabolic antenna is standard, select the Standard LNB option. The boxes "Low LO Frequency" and "High LO Frequency" will be automatically completed with values 9750 and 10600 respectively (see Figure 2.5 on the previous page).

If the LNB installed is Special, select the Special LNB option on the drop down list (see Figure 2.6 below).

"Transponder Frequency (MHz)": Enter the required transponder frequency.

"Low LO Frequency (MHz)": The value is automatically shown if Standard LNB was selected. You must manually enter this value if you have selected Special LNB.

"High LO Frequency (MHz)": As above.

"IF Band": Select Low or High from the drop down list depending on the transponder frequency: low for 10700-11700 MHz and high for 11700-12750 MHz. When the selection is complete the corresponding value will automatically be calculated by the programme and displayed in the Intermediate Frequency box.

"Input Rate (MS/s)" : This parameter, best known as Symbol Rate, is also provided in specialist magazines.

Once the different data values have been entered, click on *Save* to conclude the input settings.

"Input signal": This indicates if the streamer module has synchronised (✓) or not (✗) with the input signal. If it has not synchronised, check the different settings values entered.

The screenshot shows the 'Input' window with the following settings:

- Setting Mode:** Transponder
- Intermediate Frequency (MHz):** (empty field)
- Input Rate (MS/s):** 27.500
- LNB Type:** Special LNB
- Transponder Frequency:** (empty field)
- LO's Low Frequency (MHz):** (empty field)
- LO's High Frequency (MHz):** (empty field)
- IF Band:** High
- Input signal:** ✗
- Save** button

Figure 2.6 - Input window — Transponder Mode - Special LNB

Output Section Settings

Click on the **Settings** menu on the left of the general programme screen and click again on the *Output* option. The Output window will appear:

The screenshot shows the 'Output' window with the following configuration:

- Protocol:** UDP
- Time To Live:** 3
- QoS:** High priority video
- Total Bandwidth:** 15.2 Mbps

ON/OFF	Stream IP	SID	PID	Service	Type	Mbps	SAP ID	
☒	224.1.1.1	30201	161	TVC INT.	FV	3.7	TVC INT.	
☒	224.1.1.2	30222	167	TV GALICIA	FV	3.8	TV GALICIA	
☒	224.1.1.3	30203	163	EUSKADI TV	FV	3.8	EUSKADI TV	
☒	224.1.1.4	30202	162	ANDALUCÍA TV	FV	3.8	ANDALUCÍA TV	

Buttons: Add Stream, Update

Figure 2.7 - Output window

This window is used to select and configure the required services (TV or Radio programs) from the DVB-S input transport stream as IP streams. The window displays three boxes at the top, and in the centre it displays a table showing the IP streams already configured and which may or may not be transmitted by the streamer module (see NOTE below). For each stream it shows the multicast address and the different parameters such as the PID of the main stream or the total bandwidth in Mbps.

"Protocol": The drop down menu offers two options : UDP and UDP/RTP. UDP is a transport protocol which is not connection oriented and is particularly useful for streaming. UDP/RTP adds extra data fields so that the data flow is served at the correct speed for its projection in real time.

"Time To Live": Is a parameter used to restrict the stream multicasting range. A number between 1 and 255 is entered in this box. Each time that an IP stream passes through a router, the TTL is reduced by one unit. The stream will be rejected by any router when the TTL value is reduced to zero.

"QoS": Quality of Service. The drop down list offers five differentiated service options or *Diffserv*. These options relate to the priority that you wish to assign to the streaming packets on their routes through switches or routers that are QoS management capable:

- 1 Maximum priority
- 2 High priority video
- 3 Low priority video
- 4 Video and voice
- 5 Best effort (best effort made to correctly deliver the video data and the associated audio data)

NOTE: Configured IP Streams are those that have been created in the manner described on the following page. These streams may or may not be incorporated into the data stream depending on whether their corresponding ON/OFF boxes in the first column are checked or not. The number of checked boxes cannot be higher than 8.

The Output window allows you to perform three actions:

- *Add Stream*: This adds a new IP stream to the display table.
- *Edit Stream*: Allows you to change the parameters of the IP stream on the display table.
- *Delete Stream*: Deletes an IP stream from the display table.

Add Stream

Click on the *Add Stream* button at the bottom of the Output window (see Figure 2.7 on the previous page). The Add Stream window is displayed:

Output

Multicast Stream Address: Port: SAP ID:

(224.0.0.0 - 239.255.255.255)

Name	Service Type	SID	Main PID	Provider
☒ TVC INT.	Video Free	30201	161	TVC
☐ CNN+	Video Coded	30207	169	CNN+
☐ CANAL ESTRELLAS	Video Coded	30206	168	GALAV
☒ TV GALICIA	Video Free	30222	167	TVG
☐ FDF	Video Coded	30221	166	FDFIC
☐ TCM CLÁSICO	Video Coded	30220	165	CMACLS
☐ CNN+	Video Coded	30210	169	CNN+

Send full PMT ☒ PMT size to send 273 bytes

[x] Audio	PID	[x] Subtitles	PID	[x] Teletext	PID	[x] Other	PID
☒ Catalan	84			☒ Catalan	35	☒ -	208
						☒ -	222
						☒ -	309
						☒ -	213
						☒ -	253
						☒ -	307
						☒ -	356

Figure 2.8 - Add Stream window

The window shows all of the input DVB-S transport stream services, including different details (name, type, identifier, main PID, provider). Highlighted in orange are those services which are already configured as IP streams (seen in the display table in the Output window) and highlighted in green are those which are not yet configured.

To add a stream to the display table, select the button for the corresponding service in the first column. The line will be highlighted in pink and a group of boxes related to the elemental streams associated to the main stream of the service will appear.

The boxes at the top and middle of the screen will now be completed, and the elemental streams at the bottom will be configured:

Boxes at the top of the screen:

"Multicast Stream Address": Enter the multicast address required for the stream to be added. The available range is from 224.0.0.0 to 239.255.255.255, but it is recommended to reduce it from 224.0.1.0 to 238.255.255.255. See NOTE below.

"Port": The default value is 1234.

"SAP ID": Is the name given to the service on the subscriber's set-top box or reproducer, if the device supports SAP/SDP protocol. The name that the service has on the input transport stream is the default name.

"Channel Number": Enter the order number you want to assign to the service on the subscriber's set-top box or reproducer, if the device supports SAP.

"SAP Group": Select from the drop down menu the SAP group to which you want to link the service. The group will have been previously created through the SAP/SDP Channel window (see next page).

Box in the middle of the screen:

"Send full PMT": Leave this box checked if you wish to send the complete PMT table (Program Map Table) for the service. Otherwise, if you would like to refrain from sending certain PIDs that are not relevant to the elemental streams associated with the main stream (bottom boxes) remove the check from the box.

Bottom boxes:

Only in cases where the "Send full PMT" box is NOT checked can you make the selections that you wish on each of the elemental streams associated with the main stream: audio, subtitles, teletext, etc.

Once all data is entered and the appropriate selections have been made, click on *Update* to add the new IP stream to the display table in the Output window.

Edit Stream:

You can change the parameters of an IP stream displayed in the table on the Output window. Click on the icon  at the end of the line. The previously described Add Stream screen is displayed, where you can change any editable field, from the multicast address to the elemental stream selections in the boxes at the bottom.

Once all changes that you require are made, click on *Update* and the IP stream will be displayed with its new configuration in the display table in the Output window.

Delete Stream:


If you wish, you can delete an IP stream from the display table on the Output window. To do so, click on the icon  at the end of the line.

NOTE : Range 224.0.0.0 through 224.0.0.255 is reserved for local purposes (as administrative and maintenance tasks). Datagrams destined to this use are never forwarded by multicast routers.

Similarly, the range 239.0.0.0 to 239.255.255.255 has been reserved for "administrative scoping" (administratively defined topological regions).

SAP Channel Settings

Click on the **Settings** menu on the left of the general programme screen and click again on the *SAP Channel* option. The SAP Channel window will appear:



SAP Activated	☒
SAP IP address:	192.168.1.10
User:	IKUSI
Group:	IPTV
Time interval between sap announces:	5

Save

Figure 2.9 - SAP Channel window

This menu option is used to configure the announcement and service description SAP/SDP channel. SAP and SDP are two protocols for creating an EPG type program guide.

"SAP Activated": Check the box if you wish to transmit the program guide.

"SAP IP address": This data cannot be changed. It is the IP address assigned to the streamer module on the Network tab in the Configuration window (page 8).

"Username": The name entered will be transmitted on the SAP/SDP channel.

"Group": As above.

"Time interval between SAP announcements": Introduce the time interval, in seconds, at which the transmitted programmes guide will refresh.

Click on *Save* to save the SAP/SDP channel configuration data.

User Menu of the Conditional Access Module (CAM)

Click on the **Settings** menu on the left of the general programme screen and click again on the *CAM User Menu*. The CAM User Menu window will appear :




Figure 2.10 - CAM User Menu window

Click on the *Begin Conditional Access Session* button. A window showing a menu whose content depends on the inserted CAM module will appear. Figure 2.11 below shows as an example the menu presented by a particular Mediaguard CAM.

Independently of the CAM type, the different options of the initial menu are always numbered, so that the access to these is accomplished through the PC keyboard. Carrying on with the example, to accede to the *Card* option you must press the key "1" of the keyboard (number 1 will be shown in the lower box, see Figure 2.12) and next you must click on the *Send* button. The window of Figure 2.13 appears. This window, besides to inform about the card serial number and the stored maturity level, allows to change this level through the *Change Maturity* option, via keyboard and *Send* button, as explained.




Figure 2.11




Figure 2.12




Figure 2.13

The way to accede to the different options of the menu has been clear, so it is not necessary to follow with the example. The procedure is, as aforesaid, similar for all type of CAM modules. When in doubt, contact the vendor of the module.



Note

The correct programme de-encrypting is guaranteed only with CAMs validated by IKUSI. Consult on www.ikusi.com the operativity of your CAM.

SNMP Configuration

Click on the **Settings** menu on the left of the general programme screen and click again on the *SNMP* option. The SNMP Agent window will appear:

Configuration:		Traps:	
MIB:	Download		
SNMP Agent:	☒		
SNMP manager IP:		Hardware:	☐ ☐
Community:	public	Input:	☒ ☐
Activate CFP-702:	☒	DiSEqC:	☐ ☐
Identify CFP-702:		CAM:	☐ ☐
Minimum Alarm Duration:	0 Seconds	ColdStart:	☐ ☐
Send Traps Continuously:	☐	WarmStart:	☒ ☒
Traps Sendings:	1	CFP Temperature:	☐ ☐
Time between Sendings:	0 Seconds	CFP Voltage:	☐ ☐
Time Sending Traps with ACK:	1 Seconds	Status:	☒ ☐
		Time between Sendings:	10 Seconds

Figure 2.14 - SNMP Agent window

This window is used to configure the notification of determined traps the SNMP manager (management station). It has two sections: **Configuration** and **Traps**.

Configuration Section :

"MIB" : Click on *Download* to download the MIB of the SNS-101 streamer.

"SNMP Agent" : Tick the box if you want to activate the SNMP agent implemented in the streamer module.

"SNMP Manager IP" : Enter the IP address of the manager.

"Community" : Enter the desired name for the group formed by the streamers and power supplies of the present SNS headend, and by the manager.

"Activate CFP-702" : Tick the box in the case the streamer module is linked to a CFP-702 power supply and you want to integrate this into the management system. (See Fig. 2.15 on next page).

"Identify CFP-702" : Enter a name for the CFP-702 linked to the present streamer module.

"Minimum Alarm Duration" : Enter the minimum duration in seconds of an alarm event so that it be considered as such by the SNMP manager.

"Send Traps Continuously" : Tick the box if you want that to an alarm event the related trap be sent repeatedly to the manager. If this box is ticked, the two next ones are disabled.

"Trap Sendings" : Enter the times to an alarm event you want to send the corresponding trap to the manager.

"Time between Sendings" : It is related to the box before. Enter the time in seconds between the trap sendings.

"Time Sending Traps with ACK" : It is applicable to traps with ACK enabled. Enter the maximum time in seconds to an alarm event the trap will be being sent continuously until having an acknowledgement from the manager.

Traps Section :

You select here the streamer parameters whose alarm status generate traps, either with or without acknowledgement.

"Hardware" : Tick the box for sending an alarm trap when there be an anomaly in the streamer's circuitry. If you want to receive an acknowledgement from the SNMP manager, tick also the Enable ACK box at right.

"Input" : Idem when there be no synchronisation with the input signal.

"DiSEqC" : Idem when the DiSEqC fonction is not available or doesn't work.

"CAM" : Idem when the CAM module doesn't work properly or is not installed.

"ColdStart" : Idem when there be a Cold Start (the power is turned off then back on).

"WarmStart" : Idem when the module is rebooted (through the Shutdown card of the Configuration window, see page 9).

"CFP Temperature" : It is applicable only if the streamer module is linked to a CFP-702 power supply, with the object of incorporating this to the SNMP system. It is related to the internal temperature of the power supply. Tick the box so that the alarm trap be transmitted when this temperature exceeds the established limits.

"CFP Voltage" : Idem in relation to the +12V output voltage of the power supply.

"Status" : Tick the box for sending a "summary" trap with the current status of the most outstanding parameters.

"Time between Sendings" : This box is enabled only if you ticked the previous one. Enter the desired time in seconds to pass between "summary" trap sendings.





Figure 2.15 - Example of SNS Headend with monitor redundant power system. Contains 7 SNS-101 streamers and 2 CFP-702 power supplies.

Chapter Three - SNS-101 Streamer Status Information

In this Chapter

- Status Information



Status Information

Click on the **Status** menu on the left of the general programme screen and click again on the *Status Information* option. The Status Information window appears:

Status information	
Hardware alarm:	✓
Input	✓
CAM:	✗
DiSEqC:	✓
BER:	2.4E-5
C/N(dB):	12.7
Number of streams:	0
Output Rate (Mbps):	0.0
Information sent (MB):	6.3553E+2
Information received (MB):	2.0607E+1

Figure 3.1 - Status Information window

This window gives you information on the existence of alarms for module operations and on the importance reception and transmission parameters:

"Hardware Alarm" : Indicates whether there is an anomaly in the module's circuitry. A ✓ mark indicates correct status or operations and a cross ✗ warns of an alarm situation.

"Input": Indicates whether there is (✓) synchronisation or not (✗) with the input signal. In cases where there is not synchronisation, check the settings made in the Input Settings (pages 15 to 17).

"CAM": Indicates whether the CAM module works properly (✓) or either it doesn't work properly or no CAM is installed (✗).

"DiSEqC": Indicates whether the DiSEqC function is available in the module (✓), being it activated or not, or either it is not available or it doesn't work (✗).

"BER": Expresses in scientific notation the channel BER value for the input signal.

"C/N (dB)": The value in dB of the carrier/noise ratio of the input signal.

"Number of Streams": Number of IP streams currently transmitted by the SNS-101 module.

"Output Rate": Value in Mbps.


"Information Sent (MB)": Expresses in scientific notation, the amount of information (in megabytes) which has been transmitted by the internal web server since the last module reset.

"Information Received (MB)": The same for information received.

Chapter Four - SNS-101 Streamer Reports

In this Chapter

- Input Services
- Output Streams
- System Logs



Input Services

Click on the **Reports** menu on the left of the general programme screen and click again on the *Input Services* option. The Input Services window appears:

Input Services				
Name	Service Type	SID	Main PID	Provider
TVC INT.	Video Free	30201	1025	TVC
PID	Type	Language		
161	ITU-T Rec. H.262 ISO/IEC 13818-2 Video	-		
84	ISO/IEC 13818-3 Audio	Catalan		
35	ITU-T Rec. H.222.0 ISO/IEC 13818-1 PES packets containing private data	Catalan		
208	unknown code = 192	-		
222	unknown code = 192	-		
309	unknown code = 192	-		
213	User Private	-		
253	User Private	-		
307	User Private	-		
356	User Private	-		
148	User Private	-		
151	User Private	-		
888	User Private	-		

Name	Service Type	SID	Main PID	Provider
CNN+	Video Coded	30207	1029	CNN+
PID	Type	Language		
169	ITU-T Rec. H.262 ISO/IEC 13818-2 Video	-		
116	ISO/IEC 13818-3 Audio	Spanish		
59	ITU-T Rec. H.222.0 ISO/IEC 13818-1 PES packets containing private data	Spanish		


Figure 4.1 - Input Services Window

The Input Services window shows the full information on each of the services contained in the DVB-S input transport stream. In particular, it specifies the values of the following parameters for each service:

- Name of the service
- Type
- SID (service identifier)
- PID of the main stream
- Service Provider
- PID, Type and Language of each one of the elemental streams associated with the main stream

Output Streams

Click on the **Reports** menu on the left of the general programme screen and click again on the *Output Streams* option. The Output Streams window will appear:



The screenshot shows a window titled "Output Streams" with a maroon header. Below the header, it states "Total output bandwidth : 15.8 Mbps". The main content is a table with the following data:

ON/OFF	Stream IP	SID	PID	Service	Type	Mbps	SAP ID	Provider
ON	224.1.1.1	30201	161	TVC INT.	Video Free	3.7	TVC INT.	TVC

PID	Type	Language	Selected
161	ITU-T Rec. H.262 ISO/IEC 13818-2 Video	-	No
84	ISO/IEC 13818-3 Audio	Catalan	No
35	ITU-T Rec. H.222.0 ISO/IEC 13818-1 PES packets containing private data	Catalan	No
208	unknown code = 192	-	No
222	unknown code = 192	-	No

Figure 4.2 - Output Streams window

The Output Streams window shows all IP streams that have been created for this module. These streams may or may not be incorporated in the output data stream.

For each IP it shows the following details:

- ON/OFF (whether the stream is incorporated or not in the output data stream)
- IP Stream (multicast address)
- SID (service identifier)
- PID of the main stream
- Name of the service
- Type
- Total output bandwidth in Mbps
- SAP ID (name with which the service is announced on the subscriber's receiver)
- Service Provider
- PID, Type and Language of each one of the elemental streams associated with the main stream, indicating whether they are incorporated into the IP output transport stream or not.

IKUSI - Ángel Iglesias, S.A.

Paseo Miramón, 170
20009 San Sebastián
SPAIN

Tel.: +34 943 44 88 00
Fax: +34 943 44 88 11

www.ikusi.com

